



RADIO-CONTROLLED WEATHER STATION • **Art.-Nr.: 4-LD6162-1-2**

(GB) RADIO-CONTROLLED WEATHER STATION

Usage and safety instructions

(HU) RÁDIÓVEZÉRELT IDŐJÁRÁSÁLLOMÁS

Használati és biztonsági utasítások

(SI) RADIJSKO VODENA VREMENSKA POSTAJA

Navodilo za uporabo in varnostno navodilo

(CZ) RÁDIOVÁ METEOROLOGICKÁ STANICE

Návod k obsluze a bezpečnostní upozornění

(SK) METEOSTANICA

Pokyny pre obsluhu a bezpečnostné pokyny

(DE) (AT) (CH) FUNK-WETTERSTATION

Bedienungs- und Sicherheitshinweise

IAN 392071_2201

(HU) (SI) (CZ)

Ⓒ GB	Usage and safety instructions.....	- 1 -
Ⓒ HU	Használati és biztonsági tanácsok	- 25 -
Ⓒ SI	Navodilo za uporabo in varnostno navodilo.....	- 51 -
Ⓒ CZ	Návod k obsluze a bezpečnostní upozornění	- 75 -
Ⓒ SK	Pokyny pre obsluhu a bezpečnostné pokyny.....	- 99 -
Ⓒ DE Ⓒ AT Ⓒ CH	Bedienungs- und Sicherheitshinweise	- 123 -

Table of Contents

Table of Contents.....	- 1 -	Select temperature unit	- 17 -
Introduction	- 2 -	Set temperature warning	- 17 -
Approved use	- 2 -	Enable and disable the	
Scope of delivery	- 2 -	temperature warning.....	- 17 -
Technical specifications	- 2 -	Frost warning	- 17 -
Radio-controlled weather station.....	- 2 -	Weather forecast.....	- 18 -
Plug-in power supply	- 2 -	Weather symbols	- 18 -
Outdoor sensor.....	- 2 -	Trends	- 18 -
Explanation of symbols	- 3 -	Outdoor sensor/channel setting.....	- 18 -
Explanation of the battery symbols	- 5 -	Indoor humidity.....	- 19 -
Important safety information	- 6 -	Phases of the moon	- 19 -
Safety instructions for users.....	- 6 -	Maximum and minimum values.....	- 19 -
Safety information for the batteries	- 6 -	Battery level indicator	- 19 -
Electrical hazard	- 8 -	Restart (RESET).....	- 20 -
Hanging or positioning the device securely ..	- 9 -	Cleaning instructions	- 20 -
Hanging or setting up the		Storage.....	- 20 -
outdoor sensor securely.....	- 10 -	Simplified EU Declaration of Conformity.....	- 20 -
Description of the device	- 11 -	Disposal.....	- 20 -
Display	- 11 -	Disposing of the electrical device	- 20 -
Control panels	- 12 -	Disposal of batteries	- 21 -
Description of the outdoor sensor	- 13 -	Recycling.....	- 22 -
Starting up the device.....	- 14 -	Waste disposal.....	- 22 -
Radio reception	- 15 -	The digi-tech gmbh warranty	- 23 -
Interference with reception	- 15 -	Warranty terms.....	- 23 -
Switch radio reception off and on	- 15 -	Warranty period and statutory	
Restart radio reception.....	- 15 -	claims for defects.....	- 23 -
End radio reception	- 15 -	Scope of Warranty	- 23 -
Quick set-up.....	- 15 -	Processing in the event of	
Basic settings	- 15 -	a warranty claim	- 23 -
Adjusting the time zone	- 16 -	Order Service	- 24 -
12/24-hour time format.....	- 16 -	Service.....	- 24 -
Switch on/dim display illumination	- 16 -	Supplier	- 24 -
Alarm	- 16 -		
Setting the alarm.....	- 16 -		
Activate or deactivate the alarm	- 16 -		
Snooze function (SNOOZE)	- 17 -		
Switch off the alarm.....	- 17 -		
Temperature	- 17 -		

Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!