


hama

00
201663

"PD20-HD"

20000 mAh

Power Pack



Operating Instructions

GB

Bedienungsanleitung

D

Mode d'emploi

F

Instrucciones de uso

E

Gebruiksaanwijzing

NL

Istruzioni per l'uso

I

Instrukcja obsługi

PL

Használati útmutató

H

Manual de utilizare

RO

Návod k použití

CZ

Návod na použitie

SK

Manual de instruções

P

Bruksanvisning

S

Руководство по эксплуатации

RUS

Работна инструкция

BG

Οδηγίες χρήσης

GR

Kullanma kılavuzu

TR

Käyttöohje

FIN

Thank you for choosing a Hama product.

Take your time and read the following instructions and information completely. Please keep these instructions in a safe place for future reference. If you sell the device, please pass these operating instructions on to the new owner.

1. Explanation of warning symbols and notes

Warning



This symbol is used to indicate safety instructions or to draw your attention to specific hazards and risks.

Note



This symbol is used to indicate additional information or important notes.

High-density Li-polymer cells

This product contains high-density Li-polymer cells. High-density cells were developed primarily for smartphone production in order to accommodate the new very high demands in terms of capacity and performance with small space requirements. These new generations of Li-polymer cells allow a lightweight and compact design with comparatively high capacity.

2. Package contents

- "PD20-HD" Power Pack, 20000 mAh
- USB-C to USB-C cable
- These operating instructions

3. Safety instructions

- Use the product only for the intended purpose.
- Protect the product from dirt, moisture and overheating and use it in dry environments only.
- Do not use the product in the immediate vicinity of heaters, other heat sources or in direct sunlight.
- As with all electrical products, this device should be kept out of the reach of children.
- Do not drop the product and do not expose it to any major shocks.
- Do not operate the product outside the power limits specified in the technical data.
- Do not open the device or continue to operate it if it becomes damaged.
- Dispose of packaging material immediately in accordance with the locally applicable regulations.
- The battery is permanently installed and cannot be removed; dispose of the product as a whole in accordance with the statutory regulations.
- Do not modify the product in any way. Doing so voids the warranty.
- Do not use the product in areas in which electronic products are not permitted.
- Do not attempt to service or repair the product yourself. Leave any and all service work to qualified experts.
- Do not incinerate the battery or the product.
- Do not tamper with or damage/heat/disassemble the batteries/rechargeable batteries.

4. Operation

4.1. Charging the power pack

- Start the power pack charging process by connecting the enclosed USB-C to USB-C cable to the USB-C input on the power pack (**IN 5V/3A; 9V/2A**) and to a suitable USB-C charger. Alternatively, the power pack can also be charged via the micro-USB socket. To do this, connect a micro-USB cable to the micro-USB input (**IN 5V/2A; 9V/2A**) on the power pack and a suitable USB charger. Consult the operating instructions for the USB charger you are using.
- The charging process begins and ends automatically.
- Fully charge the power pack once before using it for the first time.

Note - capacity



- During the power pack charging process, the capacity is displayed constantly.
- Each status LED corresponds to 25% of the capacity. The permanent illumination of an LED indicates that the capacity has already been reached. If three LEDs light up and the fourth one flashes, the power pack is at least 75% charged.
- If all four status LEDs light up, the full capacity is available.
- Press the button on the power pack to switch this on and to determine the power pack's current capacity.
- Press the button twice until the status LEDs go out to switch the power pack off.

Warning – rechargeable battery



- Do not charge the power pack via your PC or notebook. The charging currents can damage the USB port on the PC or notebook.
- Only use suitable charging devices or USB connections to charge the product.
- Do not use defective chargers or USB ports and do not attempt to repair them.
- Do not overcharge the product or allow the battery to completely discharge.
- Avoid storing, charging and using in extreme temperatures and at extremely low atmospheric pressures (such as at high altitudes).
- Use the product only for the intended purpose.
- Do not use the product in the immediate vicinity of heaters, other heat sources or in direct sunlight.
- Only use the article under moderate climatic conditions.
- Do not use the product in areas in which electronic products are not permitted.
- Do not attempt to service or repair the product yourself. Leave any and all service work to qualified experts.
- Charge regularly (at least quarterly) during periods of prolonged storage.

4.2. Charging devices

- Connect the enclosed USB-C charging cable to the power pack's USB-C port (**OUT 5V/2,4A; 9V/2A; 12V/1.5A - 18W PD**) and the USB-C port on your device (mobile phone, smartphone, etc.).
- In certain circumstances, the enclosed charging / connecting cable may not match the USB port on your device. In this case, use the USB cable that came with your device.
- When using the USB-A output (**OUT 5V/2.4A; 9V/2A; 12V/1.5A - QC 3.0**) for the charging process, connect a suitable USB charging cable to the USB-A output on the power pack and the port on your device.
- The charging process begins automatically. During the charging process, the status LEDs indicate the power pack's remaining available capacity.
- The current battery charge status of your device is indicated on this.
- Terminate the charging process and switch the power pack off by pressing the button on the power pack twice. The status LEDs go out.

Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!