

# ZY2191

<b>GB</b>	<b>Laser Projector</b>
<b>CZ</b>	<b>Laser projektor</b>
<b>SK</b>	<b>Laserový projektor</b>
<b>PL</b>	<b>Projektor laserowy</b>
<b>HU</b>	<b>Lézerprojektor</b>
<b>SI</b>	<b>Laserski projektor</b>
<b>RS HR BA ME</b>	<b>Laserski projektor</b>
<b>DE</b>	<b>Laser-projektor</b>
<b>UA</b>	<b>Лазерний проєктор</b>
<b>RO</b>	<b>Proiector cu laser</b>
<b>LT</b>	<b>Lazerinis prožektorius</b>
<b>LV</b>	<b>Lāzera projektor</b>
<b>EE</b>	<b>Laserprojektor</b>
<b>BG</b>	<b>Лазерен прожектор</b>



# GB LASER PROJECTOR

## Indoor and Outdoor Laser Decorative Lighting

### Important warning:

The laser decorative light works only in the dark.

#### Note:

**Attention:** To prevent harmful laser radiation, do not use the product for purposes it was not designed for according to the manufacturer. Do not shine directly into the eyes or the face. Do not open the product under any circumstances. Do not connect to power supply while the product is still in packaging. We do not provide warranty for damage caused by incorrect use. The manufacturer bears responsibility only for damage caused during correct use.

### Safety & installation:

Before using the device, read the instruction manual carefully! Follow the safety instructions when putting the device into operation; otherwise, there could be a risk of injury to persons or damage to objects. Follow all safety instructions to avoid damage due to incorrect use! Keep the instruction manual for later use. If you pass the product on to another person, also provide them with the instruction manual.

### Important safety warnings:

1. Read and follow all safety instructions and all instructions listed on the product or enclosed with it.
2. Do not remove the information table.
3. The product may be used by children over 18 years of age. Persons with reduced physical, sensory or mental abilities may use the product only if they understand the contents of the instruction manual, will follow its instructions, and are aware of the dangers associated with the use of the product. Children must not play with the device. Children must not clean the device on their own; they must be supervised by a person older than 18 when doing so.
4. Mounting and electrical installation of the device must be done always with adherence to the relevant directives and standards, including fire-prevention regulations, after consulting a professional.
5. If used in the vicinity of a swimming pool, make sure the product is at least 3 metres away from the pool; do not use the device in the bathroom.
6. Warning: Danger of injury by electrical current. When used outside, plug the product only into protected electrical sockets (with cover). If such a socket is not available, contact a professional to ensure proper installation. Make sure the power supply unit and the cable do not prevent the closing of the socket.
7. Warning: Do not connect the product to electrical sockets which are only watertight when closed.
8. Do not disassemble the network cable; doing so creates the risk of injury by electrical current or creates a fire hazard.
9. To reduce the risk of injury by electrical current, only unplug the product from the socket when the product is turned off.
10. Do not use the product if damaged.
11. WARNING – THIS PRODUCT MUST NOT BE USED WITHOUT THE APPROPRIATE GASKETS
12. Should the light source rupture or become damaged, do not use this product or leave it connected to the power supply. Instead, dispose of it in a safe, environment-friendly way
13. The product is designed for decorative lighting.
14. The product is not a toy; do not put it in the hands of children!

Warning: If there is an air corridor within 20 km, do not point the device in that direction. If there is an airfield within 20 km of the place of use, adjust the angle of the device so that the laser lights do not shine to the sky.

### Instructions for use:

1. Take all parts of the product out of the box. If you are not using the product, store it in the box.
2. Choose a suitable spot for the device: there should be no obstacle between the device and the projection surface, so that the light can be projected without disruption.

Distance	Projection surface
3 m	20 m <sup>2</sup>
6 m	90 m <sup>2</sup>
8 m	140 m <sup>2</sup>
10 m	200 m <sup>2</sup>
12 m	280 m <sup>2</sup>
14 m	360 m <sup>2</sup>

Fig. 1



3. Screw the head onto the stake (fig. 1). Check that the head is directed at the chosen surface. Push the sharp tip of the stake completely into the ground on the chosen spot. If it is difficult to push the stake in, you can hammer the stake in gently using a rubber hammer. Never put pressure on the product.
4. Rotate the head on the stake in clockwise direction.
5. Loosen the nut, insert plastic pin into the projector head and rotate in the required direction.
6. Use an appropriate extension cable to run the device (not included in the pack). Connect the extension cable to an electrical socket.

## Warranty:

The warranty excludes all faults caused by inexpert use of the device, e.g.: overheating, change of colour, scratching, damage due to falling on the ground, attempted repair and incorrect cleaning. An exception to this is worn out optics, which are considered normal wear and tear.

## Disposal & technical specifications:

Do not throw a worn out product into municipal waste. Take it to a collection and recycling point for electrical and electronic devices. The symbol for this method of disposal is shown on the product, in the instruction manual and on the packaging. Find a collection point run by the local authority. Recycling is extremely important for the protection of the environment.

## Technical specifications:

This product complies with European standards.

Model: SL-MU5W14L (ZY2191)


Output: 220–240 V, 50/60 Hz

Laser class: 2

Output power: 1 mW

Wavelength: 532 nm, 650 nm

Temperature range: -20 °C to 40 °C



## Warning!

The laser light can only be used in temperature range of -20 °C to +40 °C. If temperature is at or below freezing point, warm up the product for 10 minutes in order to reach adequate projecting power.

## Warranty limitations:

Technical information, data and instructions for installation, operation and use correspond to the state of the device at the time of printing.

The manufacturer bears no responsibility for damage caused by not following the instruction manual, incorrect use, unauthorised modification or use, and by use of incorrect parts and components.



Do not dispose with domestic waste. Use special collection points for sorted waste. Contact local authorities for information about collection points. If the electronic devices would be disposed on landfills, dangerous substances may reach groundwater and subsequently food chain, where it could affect human health.

EMOS spol s.r.o. declares that the LASER PROJECTOR is in compliance with the essential requirements and other relevant provisions of Directive. The device can be freely operated in the EU. The Declaration of Conformity can be found at <http://www.emos.eu/download>.

# CZ LASER PROJEKTOR

## Vnitřní a venkovní laserové dekorativní světlo

### Důležité upozornění:

**Laserové dekorativní světlo funguje jenom ve tmě.**

#### Upozornění:

**Pozor:** Pro zabránění škodlivého laserového záření nepoužívejte produkt k jiným účelům, než k jakým je podle výrobce určen. Nesvitte záměrně do očí nebo do obličeje. Za žádných okolností produkt neotvírejte. Nepřipojujte k napájení, pokud je v obalu. Neposkytujeme záruku na škody způsobené nesprávným použitím. Výrobce bere odpovědnost výhradně za škody vzniklé během správného používání.

### Bezpečnost & montáž:

Před použitím zařízení si pozorně přečtěte návod k použití! Během uvádění zařízení do provozu dbejte bezpečnostních pokynů, protože může vzniknout riziko úrazu osob nebo poškození předmětů. Dodržuje všechna bezpečnostní opatření, abyste předešli škodám, způsobeným nesprávným použitím! Návod k použití si odložte pro pozdější použití. Pokud produkt předáte třetí osobě, přiložte i návod k použití.

### Důležitá bezpečnostní upozornění:

1. Přečtěte si a dodržujte všechny bezpečnostní pokyny a všechny pokyny na produktu uvedené nebo k němu přiložené.
2. Neodstraňujte tabulku údajů.
3. Produkt mohou používat děti starší 18 let. Osoby se sníženými fyzickými, senzorickými či duševními schopnostmi mohou produkt používat, jenom pokud porozumějí obsahu návodu k použití, budou ho dodržovat, a jsou si vědomi nebezpečí, spojených s používáním produktu. Děti si nesmí se zařízením hrát. Děti nesmí zařízení samy čistit, v takovém případě na ně má dohlížet osoba starší 18 let.

# Obsah je uzamčen

**Dokončete, prosím, proces objednávky.**

**Následně budete mít přístup k celému dokumentu.**



**Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:**

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne\*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

*\*) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!